

MARATHON WINDSCHILD

Marathon windshield | Pare-brise Marathon | Parabrezza Marathon | Cúpula Marathon

Art.-Nr: 14151-00x

LEGENDE/KEY/FILE LÉGENDE

-  **Anbau Tipp**
Fitting tip
Astuce de montage
-  **Achtung**
Attention
Attention
-  **Vergrößerung**
Magnification
Grossissement
-  **Montagepaste**
Fitting lubricant
Lubrifiant de montage

-  **Schraube**
Screw
Vis
-  **Schraubensicherung**
Thread locking fluid
Freiniflets
-  **Drehmoment**
Torque
Torque
-  **Reiniger**
Cleaner
Nettoyant



Management
System
Verifiziert gemäß
genehmigungs-
relevanter
Anforderungen
www.tuv.com
ID 9000012000



0302/026

3



4



Bitte alle Anbauteile lose am Fahrzeug vormontieren und ausrichten. Erst danach die Schrauben nach Vorgabe anziehen.

First, tighten all screws only loosely. After mounting all parts, the screws should be tightened to the torque specified. Tout d'abord, ne serrez pas toutes les vis sans les serrer. Après avoir monté toutes les pièces, les vis doivent être serrées au couple spécifié.