

## **Installation Guide**



Fits 2007-2014 BMW F800/700/650GS

**Parts:** MudSling 4 - zip ties

udSling **Tools:** T25 Torx Driver zip ties zip tie cut-off tool

2 - longer screws 2- rubber washers excluding 2014 F800 GSA

- 1 PLACE THE BIKE ON ITS CENTER STAND ON LEVEL GROUND.
- **2** Looking up at the underseat area, remove the two existing TORX head screws with a T25 driver.
- 3 From the right side of the bike, position the MudSling securely against the underseat area, aligning the holes of the MudSling with the holes of the screws just removed. When positioned correctly the widest part of the MudSling will rest against the frame rails that support the foorpegs.
- 4 Install the two longer TORX head screws provided with rubber washers. Loctite is not compatible with ABS plastic. If you do use it, sparingly apply only QUICKSTIX 248.
- **5** On the left side of the bike, secure the MudSling to the frame with a zip tie and trim off any exess length.



On the right side of the bike, feed the zip tie from the bottom side, up through the backside hole of the MudSling until you see it come out from behind the square tubing. Pull it out, feed it through the front hole, cinch it up securely and trim off any excess length.

**ATTENTION!** Recheck fastener tightness after the first ride. Be sure to properly set suspension pre-load for the weight being carried before riding.



WARNING AND DISCLAIMER: All parts manufactured, designed or sold by Machineart Moto ("MaMo") should be installed by a qualified motorcycle technician. The risk of injury is increased by improper installation or misuse of equipment. MaMo's customers must exercise good judgment in the use, control, alteration, part selection and installation, and maintenance of their motorcycles. In the event of a possible defect in material or design, or any other defect in a part manufactured, designed or sold by MaMo, the responsibility of MaMo is limited to a refund of the purchase price or the replacement of the part if MaMo determines the part to be defective, and subject to MaMo's inspection of the part within thirty (30) days from the date of purchase. (Note: any attempted repairs or modifications made to MaMo products will void this limited warranty). MaMo, under no circumstances will be responsible for incidental and/or consequential damages, property damage, personal injury damage, or damage, injury, cost or expense of any kind or nature whatsoever except as provided by law. MaMo makes no other warranty, express or implied, including without limitation any warranties of merchantability and fitness for a particular purpose.